

Calgary Office  
 #2, 21 Highfield Circle SE  
 Calgary, AB T2G 5N6  
 (403)259-3992

Edmonton Office  
 16304 111 Avenue  
 Edmonton, AB T5M 4G3  
 (780)486-2155

Vancouver Office  
 #10, 3671 Viking Way  
 Richmond, BC V6V 2J5  
 (604)214-9453

## Editing Internet Port Connection Server and NTRIP information

With the change over from Pleiades Data Corporation RTK corrections services to Leica's SmartNet North America will require the user to change the assigned SERVER TO USE in the Internet Port Connections.

**All support issues related to network connections, usernames and passwords, are now being handled by Leica SmartNet support. Contact: <https://support.smartnetna.com/hc/en-us/>**

Press the Star Key on your controller keyboard and select SERVER/MOUNTPOINT

Tap on the box for SERVER TO USE to open your list of available servers, then tap NEW (F2) to create a new server.

**Internet Port Connection**

Internet port: CS Internet 1  
 Server to use: **Spatial Rtk**  
 NTRIP mountpoint: PDC\_BC\_NTRIP  
 Press Source to get a list of mountpoints

**Server to Connect**

Name	IP address
MetroVancouver	gps.metrovancouver.org
Spatial Rtk	pdcrk.ca

Calgary Office  
 #2, 21 Highfield Circle SE  
 Calgary, AB T2G 5N6  
 (403)259-3992

Edmonton Office  
 16304 111 Avenue  
 Edmonton, AB T5M 4G3  
 (780)486-2155

Vancouver Office  
 #10, 3671 Viking Way  
 Richmond, BC V6V 2J5  
 (604)214-9453

**Edit Server**  
 General | NTRIP

**Server name:** SmartNet BC  
**Address:** bc.smartnetna.com  
**Port:** 10000

**Use NTRIP with this server**  
**NTRIP user ID:** your username  
**NTRIP password:** \*\*\*\*\*

Store

Enter the Server name, address and port number. Enter the username and password provided by SmartNet, and tap STORE.

**Server to Connect**

Name	IP address
MetroVancouver	gps.metrovancouver.org
SmartNet BC	bc.smartnetna.com
Spatial Link	pdcrk.ca

**Internet Port Connection**

**Internet port:** CS Internet 1  
**Server to use:** SmartNet BC  
**NTRIP mountpoint:** -----  
 Press Source to get a list of mountpoints

Source

Select the server and tap OK

Tap SOURCE (F5) to generate the list of Mountpoints.

There are two choices, MAX or NEAREST. Select the Mountpoint that matches your network type

**Internet Port Connection**

**Internet port:** CS Internet 1  
**Server to use:** SmartNet BC  
**NTRIP mountpoint:** RTCM3\_NEAR  
 Press Source to get a list of mountpoints

**Internet Port Connection**

**Internet port:** CS Internet 1  
**Server to use:** SmartNet BC  
**NTRIP mountpoint:** RTCM3\_MAX  
 Press Source to get a list of mountpoints

RTCM3\_MAX for MAX Network  
 RTCM3\_NEAR for Nearest Network